


AlcoLimit BACtrack® Smartphone Mobile Breathalyser

The AlcoLimit BACtrack Smartphone Mobile Breathalyser utilises the latest in smartphone technology to connect your breathalyser to a convenient app. using Bluetooth 4.0 - technology.

Users can test their alcohol level on-the-go, keep track of %BAC readings and upload results to Facebook and Twitter to share with friends, all in one app.

The AlcoLimit BACtrack Smartphone Mobile Breathalyser has been rigorously tested and certified under Australian Standard AS3547 for accuracy and durability.









- Guestimate when your %BAC will return to zero with the Zeroline software
- Store your results and a friend's all in one application
- View a graph of results taken over time
- Log the date and time of each test
- Tag drinks, add photos and notes to each reading
- Share results with friends on Facebook and Twitter!

The date, time and location of your results can be recorded with AlcoLimit® BACtrack Mobile Breathalyser's Worldview® software.





How it Works

Simply press the ON/OFF button to connect your AlcoLimit® BACtrack Smartphone Mobile Breathalyser to your mobile device or Apple Watch via Bluetooth.



Keep blowing long as the transmission of the t



Blow into your AlcoLimit® BACtrack Smartphone Mobile Breathalyser until the software tells you to stop.





Your Blood Alcohol Concentration (%BAC) will appear on the display within seconds providing 3 decimal place accuracy!

AlcoLimit® BACtrack Smartphone Mobile Breathalyser app will also provide information about how the alcohol is affecting your body enabling you to understand in more detail.



Best Apps of the Week: "Connect the device through Bluetooth and quickly and accurately estimate your blood alcohol level."



"At the top of the line is the BACtrack Mobile Breathalyzer. Besides the standard features, this gadget provides...an estimate of how long until you're sober."



"If you're going to shell out for a breathalyser, you might as well make it accurate. This one uses fuel cell sensors, the preferred breathalyser tech used by law enforcement...

	PRODUCT SPECIFICATIONS
Recommended Usage:	Personal
Sensor Type:	Platinum Electrochemical Fuel Cell Sensor
Accuracy:	Conforms to Australian Standard AS3547
Range %BAC :	0.000 - 0.500
Display:	via smartphone mobile device or Apple Watch
Warm-up time:	< 10 seconds
Breath Sampling Time:	5 seconds
Housing:	Shock Resistant Plastic
Weight:	47 grams
Power Source:	Internal Lithium Ion battery charged via Micro USB cable
Dimensions:	5 cm x 7 cm x 1.5 cm
Warranty:	12 Month Limited Warranty
Compatible devices:	iPhone 4S, 5, 5S, 5C; iPad 3, 4, Mini; iPod Touch 5 and upwards
Mouthpieces:	Disposable - 3 included
Accessories:	Mouthpieces Pack of 10 (ALCO-062), Pack of 50 (ALCO-063)





Please note: product specifications are subject to change without notice for the purpose of product improvement